






## BARELY THERE HEALING LIP GLOSS

This luscious lip gloss contains **DEFENSIL** to promote the healing of dry, irritated lips while protecting from other damaging stresses by protecting the skin barrier. **Dermofeel Toco 70 non GMO** contributes the healing and antioxidant properties of vitamin E while **Dermofeel GTI** adds great shine as well as long-lasting wear!

	TRADE NAME	INCI	SUPPLIER	%
<b>Phase I</b>				
	Organic Shea Butter	Butyrospermum Parkii (Shea Butter) Fruit	Kinetik Technologies	24.00
	Organic Carnauba Wax	Copernicia Cerifera (Carnauba) Wax	Kinetik Technologies	10.50
	Dermofeel® Toco 70 non-GMO	Tocopherol	Kinetik Technologies	0.50
	DEFENSIL®	Octyldodecanol, Echium Plantagineum Seed Oil, Cardiospermum Halicacabum Flower/Leaf/Vine Extract, Helianthus Annuus (Sunflower) Seed Oil Unsaponifiables	Kinetik Technologies	2.00
	Dermofeel GTI	Triisostearin	Kinetik Technologies	15.00
	ABS Pomegranate Sterols	Punica Granatum Sterols	Active Concepts	5.00
	Super Sterol Liquid	C10-30 Cholesterol/Lanosterol Esters	Croda	5.00
	Castor Oil	Ricinus Communis (Castor) Seed Oil	Various	34.00
	DC 200/12,500	Dimethicone	Dow Corning	1.00
<b>Phase II</b>				
	Vanilla Lip Fragrance #298-477	Natural Flavor	American Flavors and Fragrance	2.00
	KTZ Interfine Gold	Mica (and) Titanium Dioxide	Kobo Products	0.50
	Kobopearl Shimmer White	Mica (and) Titanium Dioxide	Kobo Products	0.30
	Meridionale Umber	Mica (and) Titanium Dioxide (and) Iron Oxide (C.I. 77491)	Kobo Products	0.10
	KTZ Bronze D OR	Mica (and) Iron Oxide (C.I. 77491)	Kobo Products	0.10

 Denotes Natural Ingredient

### Procedure:

1. Combine Phase I ingredients into main beaker and heat to 75-80°C. Mixture should be completely melted and homogenous.
2. Remove from heat. When mixture reaches 70°C, add Phase II ingredients and pour.