



## new Fluid Cleanser 128 CF

Ingredient	INCI designation	% w/w	Supplier
Sucragel CF	Capric/Caprylic Triglycerides & Glycerine & Aqua & Sucrose Laurate	30.0	Alfa Chemicals
Surfhope C-1616**	Sucrose palmitate	1.5	Mitsubishi-Kagaku Foods
Labrafac CC	Capric/Caprylic triglycerides	67.5	Gattefossé
Water	Water	1.0	



### APPEARANCE:

Clear fluid oily gel

### MANUFACTURING PROCESS:

Mix together the Surfhope C1616 and the Sucragel CF with a spatula.

Heat this mixture up to 75°C. Heat the Labrafac CC up to 75°C as well.

Start the propeller in the Sucragel CF/Surfhope C1616 mixture at quite a fast speed and then add the Labrafac CC slowly into the mixture.

Adjust the stirring speed upon the viscosity of the gel (it should increase as the oil is added).

Allow cooling down to room temperature and add water.

### STABILITY TESTS:

Stability is being monitored at 45°C

### COMMENTS:

\*\* Surfhope C-1616 can be directly replaced with **Sucrablend SP**

*This formula is presented in good faith, and we believe it is correct, but no warranty as to accuracy of results, or fitness for a particular use is given, nor is freedom from patent infringement to be inferred. It is offered solely for your consideration, investigation and verification.*

©Alfa Chemicals Ltd

Updated on 14/04/2009