

Soft & Light Body Lotion

20-13-1004

Claims: Preservative free
Cold processing

Phase	Ingredient	INCI	Supplier	%
A	Deionised Water	Aqua		73.85
	Glycerol	Glycerin		4.00
	dermosoft® LP	Caprylyl Glycol, Glyceryl Caprylate, Glycerin, Phenyl Propanol, Aqua	Dr. Straetmans	1.00
	dermofeel® G 10 LW	Polyglyceryl-10 Laurate, Aqua	Dr. Straetmans	1.00
B	dermofeel® PR	Polyglyceryl-3 Polyricinoleate	Dr. Straetmans	2.00
	dermofeel® BGC	Butylene Glycol Dicaprylate/Dicaprate	Dr. Straetmans	8.00
	Miglyol 812	Caprylic/Capric Triglyceride	Sasol	8.00
	Heliogel	Sodium Acrylates Copolymer, Hydrogenated Polyisobutene, Phospholipids, Polyglyceryl-10 Stearate, Helianthus annuus	Lucas Meyer*	1.75
	Parf.Xanadu 116052 (SCCNFP-sensitizer free)	Parfum	Symrise	0.40
				100.00

Manufacturing Procedure (Cold process):

1. Premix phases A and B separately.
2. Emulsify phase B to phase A under stirring.
3. Homogenize for 1-2 min. using an Ultra-Turrax.

Specification Values:

Appearance: White lotion.

pH: 5.6 – 6.2.

Viscosity (Brookfield: Spindle 6; Speed 10): Approx. 10.000 mPa.s.

Centrifugation (4.000 upm, 15min.): No separation.

Stability:

Stable for more than 3 months at 20°, 40°, 4°C.

* distributed
in Germany by
Dr. Straetmans GmbH

Microbiological Stability: Proven.

Disclaimer:

The information contained herein is meant to demonstrate how our products can be used. The given data are suggestions without any guarantee aimed to support customers' development. As production conditions at our customers' facilities are beyond our control we refuse to accept any liability involved in the use of our products. Please observe possible third party patent rights.