

TOTAL REPAIR FOOT MASK

ID-number
pH-value
appearance

BODY Care/RC 084
approx. 6.5
white emulsion

Phase	Substance	INCI Name EU	Pos.	% [w/w]
A	Water demin.	Aqua	1	64.40
B	Carbopol Ultrez-10	Carbomer	2	0.10
C	Sympatens/O2500	Sorbitan Stearate, Methyl Glucose Sesquistearate	3	3.00
	Sisterna SP70-C	Sucrose Stearate	4	2.00
	Lanette O	Cetearyl Alcohol	5	3.00
	Cetiol SN	Cetearyl Isononanoate	5	7.00
	Cetiol OE	Dicaprylyl Ether	5	4.00
	Cetiol V	Decyl Oleate	5	5.00
	Keltrol CG-SFT	Xanthan Gum	6	0.10
	Euxyl PE 9010	Phenoxyethanol, Ethylhexylglycerin	7	1.00
D	L-Arginine 10% solution	Arginine, Aqua	8	2.50
E	Perfume Skin Caress	Parfum	9	0.50
F	DEFENSIL®	Octyldodecanol, Echium Plantagineum Seed Oil, Helianthus Annuus Seed Oil Unsaponifiables, Cardiospermum Halicacabum Flower/Leaf/Vine Extract,	10	2.00
G	Water demin.	Aqua	1	3.00
	Ajidev ZN-100	Zinc PCA	8	0.30
H	Water demin.	Aqua	1	2.00
	Aloe Vera Powder TN 003 200x	Aloe Barbadensis Leaf Juice Powder	11	0.10

Production

Prepare A
Add B whilst stirring, heat to 70°C
Mix C, heat to 70°C, add to A/B
Homogenize shortly
Add D, homogenize strongly
Cool down to 40°C whilst stirring
Add the remaining ingredients separately, homogenize shortly
Cool down to 25°C whilst stirring

Pos. Manufacturer

1 Several
2 Lubrizol, USA
3 Kolb, Switzerland
4 Sisterna B.V., Netherland
5 Cognis, Germany
6 CP Kelco, USA
7 Schülke & Mayr, Germany
8 Ajinomoto, Japan
9 Fragrance Resources GmbH, Germany
10 RAHN AG, Switzerland
11 Terry Laboratories Inc., USA

Disclaimer:

The information contained herein is, to our best knowledge, true and accurate, but all recommendations or suggestions are made without guarantee. It shows a formula thought as a support by developing with our raw materials.