

Wellness Cream

L014-2.01-208

Claims: Preservative free, Perfume free
Calming

Phase	Ingredient	INCI	Supplier	%
A	Deionised Water	Aqua		67.18
	dermofeel® PA-3	Sodium Phytate, Aqua	Dr. Straetmans	0.10
	Glycerol	Glycerin		3.00
	dermosoft® Octiol	Caprylyl Glycol	Dr. Straetmans	0.72
	dermosoft® GMCY	Glyceryl Caprylate	Dr. Straetmans	0.12
	Tinosorb M	Methylene Bis-Benzotriazolyl Tetramethylbutylphenol	Ciba	2.00
B	dermofeel® SL	Sodium Stearoyl Lactylate	Dr. Straetmans	1.50
	Tego Care 450	Polyglyceryl-3 Methyl-glucose Distearate	Degussa	3.00
	Crodamol OC	Ethylhexyl Cocoate	Croda GmbH	6.00
	Phytosqualan	Squalane	Sophim	5.00
	Cutina GMS	Glyceryl Stearate	Cognis	3.00
	Lanette 16	Cetyl Alcohol	Cognis	1.00
	dermofeel® BGC	Butylene Glycol Dicaprylate/Dicaprate	Dr. Straetmans	2.50
	dermofeel® Toco 70	Tocopherol, Helianthus Annuus (Sunflower) Seed Oil	Dr. Straetmans	0.03
C	Cosmedia SP	Sodium Polyacrylate	Cognis	0.35
	dermofeel® BGC	Butylene Glycol Dicaprylate/Dicaprate	Dr. Straetmans	0.50
D	Isocell Care	Aqua, Lecithin, Glycerin, Butylene Glycol, Sodium Styrene Acrylates/Copolymer	Lucas Meyer*	1.00
	Ethanol	Alcohol denat.		3.00
				100.00

Manufacturing Procedure:

1. Heat phases A and B separately up to 80 °C. Add B to A. Homogenize for 1-2 min.
2. Add premix of phase C while homogenizing.
3. Start to cool down and add **Isocell Care** below 40 °C under stirring.
4. Cool further down to 35 °C and add alcohol.

Specification Values:

Appearance: Light yellow emulsion.

pH: 6.0 – 6.5.

Viscosity (Brookfield: Spindle 6; Speed 10): 25.000 – 30.000 mPa.s.

Centrifugation (5.000 rpm, 2.900 RZB, 10 min.): No separation.

Stability: Stable for more than 3 months at 20°, 40°, 4°C.

* distributed
in Germany by
Dr. Straetmans GmbH

Microbiological Stability: Proven.

Disclaimer:

The information contained herein is meant to demonstrate how our products can be used. The given data are suggestions without any guarantee aimed to support customers' development. As production conditions at our customers' facilities are beyond our control we refuse to accept any liability involved in the use of our products. Please observe possible third party patent rights.