

## ANTI-AGEING EYE TREATMENT

**ID-number**  
pH-value  
appearance

**SPECIALS/RC 087**  
approx. 6.5  
white emulsion

Phase	Substance	INCI Name EU	Pos.	% [w/w]
A	Water demin.	Aqua	1	63.60
	Glycerin 86%	Glycerin	1	4.00
B	Carbopol Ultrez-20	Acrylates/C10-30 Alkyl Acrylate Crosspolymer	2	0.10
C	Sisterna SP30-C	Sucrose Distearate	3	2.40
	Sisterna SP70-C	Sucrose Stearate	3	0.80
	Lanette O	Cetearyl Alcohol	4	1.00
	Cetiol 868	Ethylhexyl Stearate	4	10.00
	Polysynlane	Hydrogenated Polyisobutene	5	7.00
	Amihope LL	Lauroyl Lysine	6	0.50
	Euxyl PE 9010	Phenoxyethanol, Ethylhexylglycerin	7	1.00
	Keltrol CG-SFT	Xanthan Gum	8	0.25
D	L-Arginine 10% solution	Arginine, Aqua	6	2.00
E	Perfume Flowerbeat	Parfum	9	0.15
F	CellActive®- HYDRO	Glycerin, Aqua, Pyrus Malus Fruit Extract, Pectin, Chlorella Vulgaris/Lupinus Albus Protein Ferment	10	2.00
G	LIFTONIN®	Aqua, Glycerin, Panicum Miliaceum Seed Extract, Tannic Acid	10	2.00
H	RADICARE®	Aqua, Melissa Officinalis Leaf Extract, Disodium Rutinyl Disulfate, Hordeum Distichon Extract	10	0.20
I	Simulgel EPG	Sodium Acrylate/Acryloyldimethyl Taurate Copolymer, Polyisobutene, Caprylyl Capryl Glucoside	11	3.00

### Production

Prepare A  
Add B whilst stirring, heat to 70°C  
Mix C, heat to 70°C, add to A/B  
Homogenize shortly  
Add D, homogenize strongly  
Cool down to 40°C whilst stirring  
Add E-H separately, homogenize shortly  
Add I, homogenize until homogenous  
Cool down to 25°C whilst stirring

### Pos. Manufacturer

1 Several  
2 Lubrizol, USA  
3 Sisterna B.V., Netherland  
4 Cognis, Germany  
5 NOF, Japan  
6 Ajinomoto, Japan  
7 Schülke & Mayr, Germany  
8 CP Kelco, USA  
9 Fragrance Resources GmbH, Germany  
10 RAHN AG, Switzerland  
11 Seppic, France

### **Disclaimer:**

The information contained herein is, to our best knowledge, true and accurate, but all recommendations or suggestions are made without guarantee. It shows a formula thought as a support by developing with our raw materials.