

## DNA PROTECTION EYE CONTOUR OPTIMIZER

<b>ID-number</b>	<b>FACE Care/RC 170</b>
pH-value	none
appearance	white water in oil emulsion
specialities	preservative-free

Phase	Substance	INCI Name EU	Pos.	% [w/w]
A	Water demin.	Aqua	1	39.30
	Dermosoft GMCY	Glyceryl Caprylate	2	0.50
	Glycerin 86%	Glycerin	1	15.00
	Sodium Chloride	Sodium Chloride	1	1.00
	Citric Acid solution 10%	Citric Acid, Aqua	1	2.50
B	Water demin.	Aqua	1	5.00
	Dermosoft 688	Parfum	2	0.20
	NaOH solution 10%	Sodium Hydroxide, Aqua	1	2.00
C	Magnesium Stearate	Magnesium Stearate	1	2.00
	Dermofeel PO	Glyceryl Oleate/Elaidate	2	1.00
	Cutina HR	Hydrogenated Castor Oil	3	2.00
	Myritol 312	Caprylic/Capric Triglyceride	3	15.00
	Dermofeel PR	Polyglyceryl-3 Polyricinoleate	2	3.00
	Dermofeel TC-7	Triheptanoin	2	2.00
	Sunflower Oil	Helianthus Annuus Seed Oil	1	7.00
D	Perfume Larina	Parfum	4	0.50
E	CELLIGENT®	Helianthus Annuus Seed Oil, Ethyl Ferulate, Polyglyceryl-5 Trioleate, Rosmarinus Officinalis Leaf Extract, Aqua, Disodium Uridine Phosphate	5	2.00

### Production

Mix A, heat to 75°C  
Mix B, heat to 75°C  
Add B to A whilst stirring  
Mix C, heat to 75°C  
Add A/B very slowly to C, homogenize  
Cool down to 40°C while stirring, add D and E separately,  
homogenize  
Cool to 25°C while stirring, homogenize strongly

### Pos. Manufacturer

1 Several  
2 Dr. Straetmans, Germany  
3 Cognis, Germany  
4 Fragrance Resources GmbH, Germany  
5 RAHN AG, Switzerland

### **Disclaimer:**

The information contained herein is, to our best knowledge, true and accurate, but all recommendations or suggestions are made without guarantee. It shows a formula thought as a support by developing with our raw materials.